

FIG. 2



(Continued)


db 27h, 00h ;ADCINC12_1_CounterCR0
db 25h, 00h ;ADCINC12_1_CounterDR1
db 26h, 00h ;ADCINC12_1_CounterDR2
; Instance name ADCINC12_1, Block Name TMR(DBA00)
db 23h, 00h ;ADCINC12_1_TimerCR0
db 21h, 00h ;ADCINC12_1_TimerDR1
db 22h, 00h ;ADCINC12_1_TimerDR2
; Instance name Counter16_1, User Module Counter16
; Instance name Counter16_1, Block Name CNTR16_LSB(DBA02)
db 2bh, 00h ;Counter16_1_CONTROL_LSB_REG
db 29h, 80h ;Counter16_1_PERIOD_LSB_REG
db 2ah, 64h ;Counter16_1_COMPARE_LSB_REG
; Instance name Counter16_1, Block Name CNTR16_MSB(DBA03)
db 2fh, 00h ;Counter16_1_CONTROL_MSB_REG
db 2dh, 00h ;Counter16_1_PERIOD_MSB_REG
db 2eh, 00h ;Counter16_1_COMPARE_MSB_REG
; Instance name DAC8_1, User Module DAC8
; Instance name DAC8_1, Block Name LSB(ASB11)
; Instance name DAC8_1, Block Name MSB(ASA21)
; Instance name INSAMP_1, User Module INSAMP
; Instance name INSAMP_1, Block Name INV(ACA01)
; Instance name INSAMP_1, Block Name NON_INV(ACA00)
; Instance name INSAMP_2, User Module INSAMP
; Instance name INSAMP_2, Block Name INV(ACA03)
; Instance name INSAMP_2, Block Name NON_INV(ACA02)
; Instance name PWM16_1, User Module PWM16
; Instance name PWM16_1, Block Name PWM16_LSB(DCA04)
db 33h, 00h ;PWM16_1_CONTROL_LSB_REG
db 31h, 37h ;PWM16_1_PERIOD_LSB_REG
db 32h, 64h ;PWM16_1_PWDITH_LSB_REG
; Instance name PWM16_1, Block Name PWM16_MSB(DCA05)
db 37h, 00h ;PWM16_1_CONTROL_MSB_REG
db 35h, 00h ;PWM16_1_PERIOD_MSB_REG
db 36h, 00h ;PWM16_1_PWDITH_MSG_REG
; Instance name UART_1, User Module UART
; Instance name UART_1, Block Name RX(DCA07)
db 3fh, 00h ;UART_1_RX_CONTROL_REG
db 3dh, 00h ;UART_1_
db 3eh, 00h ;UART_1_RX_BUFFER_REG
; Instance name UART_1, Block Name TX(DCA06)
db 3bh, 00h ;UART_1_TX_CONTROL_REG
db 39h, 00h ;UART_1_TX_BUFFER_REG
db 3ah, 00h ;UART_1_
db ffh

; ~~psoc~~ Configuration file trailer ~~psoc~~ Config.asm

RECEIVED
JAN - 9 2004
TECHNOLOGY CENTER 2800

Fig. 7C

BEST AVAILABLE COPY



~~PSoc~~Config.asm

; This file is generated by the Device Editor on Application Generation.
; It contains code which loads the configuration data table generated in
; the file ~~PSoc~~ConfigTBL.asm
;

export LoadConfigInit
export _LoadConfigInit
export LoadConfig_project
export _LoadConfig_project

FLAG_CFG_MASK: equ 10h ;M8C flag register REG address bit
mask
END_CONFIG_TABLE: equ ffh ;end of config table indicator

_LoadConfigInit:
LoadConfigInit:
lcall LoadConfig_project

ret

;
; Load Configuration project
;

_LoadConfig_project:

LoadConfig_project:

or F, FLAG_CFG_MASK ;set for
bank 1
mov A, >LoadConfigTBL_project_Bank1 ;load bank 1 table
mov X, <LoadConfigTBL_project_Bank1
call LoadConfig ;load the
bank 1 values
and F, ~FLAG_CFG_MASK ;switch
to bank 0
mov A, >LoadConfigTBL_project_Bank0 ;load bank 0 table
mov X, <LoadConfigTBL_project_Bank0
call LoadConfig ;load the
bank 0 values
ret

;

; LoadConfig

;

; This function is not exported. It assumes that the address of the table
; to be loaded is contained in the X and A registers as if a romx instruction

RECEIVED
JAN - 9 2004
TECHNOLOGY CENTER 2800

Fig. 8A

BEST AVAILABLE COPY



;; ADCINC12.asm

;; Assembler source for the 12 bit Incremental
;A/D converter.

export ADCINC12_1_Start
export _ADCINC12_1_Start
export ADCINC12_1_SetPower
export _ADCINC12_1_SetPower
export ADCINC12_1_Stop
export _ADCINC12_1_Stop
export ADCINC12_1_GetSamples
export _ADCINC12_1_GetSamples
export ADCINC12_1_StopAD
export _ADCINC12_1_StopAD
export ADCINC12_1_flsData
export _ADCINC12_1_flsData
export ADCINC12_1_iGetData
export _ADCINC12_1_iGetData
export ADCINC12_1_ClearFlag
export _ADCINC12_1_ClearFlag

include "ADCINC12_1.inc"
include "m8c.inc"

LowByte: equ 1
HighByte: equ 0

;;-----
;; Start:
;; SetPower:
;; Applies power setting to the module's analog
;; ~~psoc~~ block. *programmable system*
;; INPUTS: A contains the power setting
;; OUTPUTS: None.

;;-----
ADCINC12_1_Start:
_ADCINC12_1_Start:
ADCINC12_1_SetPower:
_ADCINC12_1_SetPower:
and A,03h
or A,f0h

mov reg[ADCINC12_1_AtoDcr3],A
ret

;;-----
;; Stop:
;; SetPower:
;; Removes power from the module's analog
;; ~~psoc~~ block. *programmable system*
;; INPUTS: None.
;; OUTPUTS: None.

;;-----
ADCINC12_1_Stop:
_ADCINC12_1_Stop:
and reg[ADCINC12_1_AtoDcr3], -03h
ret

;;-----
;; Get_Samples:
;; SetPower:
;; Starts the A/D convertor and will place data in
;; memory. A flag
;; is set whenever a new data value is available
;; INPUTS: A passes the number of samples to
;; is continuous).
;; OUTPUTS: None.

;;-----
ADCINC12_1_GetSamples:
_ADCINC12_1_GetSamples:
mov [ADCINC12_1_bIncrC],A ;number
of samples
or reg[INT_MSK1],(ADCINC12_1_TimerMask |
ADCINC12_1_CounterMask)

;;Enable both interrupts
mov [ADCINC12_1_cTimerU],0 ;Force the
;Timer to do one cycle of rest
or reg[ADCINC12_1_AtoDcr3],10h ;force the
;Integrator into reset
mov [ADCINC12_1_cCounterU],ffh ;Initialize
;Counter

mov reg[ADCINC12_1_TimerDR1],ffh
mov reg[ADCINC12_1_CounterDR1],ffh
mov reg[ADCINC12_1_TimerCR0],01h ;enable
the Timer
mov [ADCINC12_1_fIncr],00h ;A/D Data
Ready Flag is reset
ret


Fig.94

BEST AVAILABLE COPY

RECEIVED

JAN-9 2004

TECHNOLOGY CENTER 2800



1300

; Interrupt Vector Table

; Interrupt vector table entries are 4 bytes long
; and contain the code
; that services the interrupt (or causes it to be
; serviced).
;-----

AREA TOP(ROM, ABS)

org 0 ; Reset Interrupt Vector
jmp __start ; First instruction
; executed following a Reset

org 04h ; Supply Monitor Interrupt
; Vector
// call void_handler
reti

org 08h ; ~~PSoc~~ Block DBA00
; Interrupt Vector

1305 jmp ADCINC12_1_TMR_INT
reti

org 0Ch ; ~~PSoc~~ Block DBA01
; Interrupt Vector

1305 jmp ADCINC12_1_CNT_INT
reti

org 10h ; ~~PSoc~~ Block DBA02
; Interrupt Vector
// call void_handler
reti

org 14h ; ~~PSoc~~ Block DBA03
; Interrupt Vector
jmp Counter16_1INT
reti

org 18h ; ~~PSoc~~ Block DCA04
; Interrupt Vector
// call void_handler
reti

org 1Ch ; ~~PSoc~~ Block DCA0
; Interrupt Vector
jmp PWM16_1INT
reti

org 20h ; ~~PSoc~~ Block DCA06
; Interrupt Vector
jmp UART_1TX_INT
reti

org 24h ; ~~PSoc~~ Block DCA07
; Interrupt Vector
1305 jmp UART_1RX_INT
reti

org 28h ; Analog Column 0
; Interrupt Vector
// call void_handler
reti

org 2Ch ; Analog Column 1
; Interrupt Vector
// call void_handler
reti

org 30h ; Analog Column 2
; Interrupt Vector
// call void_handler
reti

org 34h ; Analog Column 3
; Interrupt Vector
// call void_handler
reti

org 38h ; GPIO Interrupt Vector
// call void_handler
reti

org 3Ch ; Sleep Timer Interrupt
; Vector
jmp SleepTimerISR
reti

TECHNOLOGY CENTER 2800

JAN - 9 2004

RECEIVED

Fig. 13A

BEST AVAILABLE COPY



1350

1352

1353

1351

boot.asm	Interrupt Name	Data Sheet	Interrupt Name	Type
start		Reset		Fixed
Interrupt1		Supply Monitor		Fixed
Interrupt2		DBA00		PSoc Block
Interrupt3		DBA01		PSoc Block
Interrupt4		DBA02		PSoc Block
Interrupt5		DBA03		PSoc Block
Interrupt6		DCA04		PSoc Block
Interrupt7		DCA05		PSoc Block
Interrupt8		DCA06		PSoc Block
Interrupt9		DCA07		PSoc Block
Interrupt10		Analog Column 0		PSoc Block
Interrupt11		Analog Column 1		PSoc Block
Interrupt12		Analog Column 2		PSoc Block
Interrupt13		Analog Column 3		PSoc Block
Interrupt14		GPIO		Fixed
Interrupt15		Sleep Timer		Fixed

Programmable System
Programmable System
Programmable System
Programmable System
Programmable System
Programmable System
Programmable System
Programmable System
Programmable System
Programmable System
Programmable System
Programmable System
Programmable System
Programmable System
Programmable System

Fig. 13B

RECEIVED
JAN - 9 2004
TECHNOLOGY CENTER 2800